

DYNAMIC CHECKWEIGHERS CW 40K



Citizen[®]
ISO 9001 : 2008 CERTIFIED



CE M 09 1383



Features :

- Designed for Control of packaged & Unpackaged Goods.
- Detecting Theory : Digital Weighing Sensor, EMFC Sensor (Optional)
- HACCP, CMP & FDA Approved
- Automatic Weighing Compensation & Zero Tracking
- Strong Stainless Steel Structure (S.S. 301) Mild Steel (Optional)
- Advance DSP Technology with Digital Signal Filter
- Based on 32 Bit High Speed CPU / Industrial PC Technology with Windows Embedded System (Optional)
- Graphical with Touch Screen Display
- Built-in Power Stabilizer
- Buzzer & Lamp Alarming with Rejectors
- 100 Products Preset; Easy to Edit & Recall
- Data Storage & Data Printout ready
- 2000 Sorting Reports
- RS-232 (Standard), USB & Ethernet Interface (Optional)
- Easy \pm Tolerance Control
- Easy Interface in Existing Production Lines
- Adjustable Bolt Speed
- Belt Speed : Upto 120 m/min. (180Hz)
- Rapid Change of Belts
- Anti-Vibration Legs with Height Adjustment
- Bar Graphs, Pie Diagrams & Statistical Data (Optional)
- Database in MS Access & SQL Server (Optional)
- Remote Monitoring of Live Operation (Optional)
- Feedback Signaling for / Dosing Systems (Optional)
- Control thru the Single Software for Metal Detectors, Dosing Systems, Signaling Devices, Conveyor Belts, Label / Inkjet Printers, Barcode Readers, Backup Devices, etc..... (Optional)



Rejectors



Pusher



Air Jet



Flipper Type



Falling Drop

Technical data:

MODEL	CW 40K
Max capacity	100 ~ 40kg
Accuracy (g)*	\pm 20kg
Reject Systems	Air Jet Reject / Flapper / Falling Drop
IP Rating	IP 66 / 67
Power Supply	AC 110V / 220V 50-60Hz
Working Temperature	AC 10° \pm 40°C
Display	Graphical with touch screen

* Depends upon nature & weight of Product, Speed, Transport behaviour and environmental conditions.

WORLDWIDEMARKETING:

CITIZEN SCALE (I) PVT. LTD.

Unit No. E2, Plot No. 11, WICEL Estate, Opp. Seepz Gate No.1, Andheri (E), Mumbai 400 093. (INDIA)
Tel. : +91-22-4243 7700 • Fax : +91-22-4243 7800 • E:mail : sales@citizenscales.com • Web : www.citizenscales.com