

METAL SEPERATOR



CE M 1383



Features :

- Designed for control of packaged & Unpackaged Goods
- Detecting Theory : Balance Coil & Electromagnetic Induction
- HACCP, GMP & FDA Approved
- Detects all Ferrous Metal & Non-Ferrous Metal, S.S., etc.
- Easy Detecting the ferrous in Aluminium Foil Package, suitable for secondary safety inspection
- Closed Magnetic Loop Detection Head
- Detection Adjustment P: 1-100 Steps
- Strong Stainless Steel Structure (S.S. 304), Mild Steel (Optional)
- Advance DSP Technology with Digital Signal Filter
- Based on 32 Bit High speed CPU
- Improved product "Self-Learning" Functions
- Multi Function Operating System
- Graphical with Touch Screen Display
- Built-in Power Stabilizer
- 100 Products Preset; Easy to Edit & Recall
- Data Storage & Data Printout ready
- 1000 Detection Lage
- RS-232 (Standard), USB & Ethernet Interface (Optional)
- Easy Integration in Existing Production Lines
- Adjustable Belt Speed
- Belt Speed : 32 m/min. (50Hz), 40m/min. (60Hz) (adjustable)
- Buzzer & Lamp Alarming with Rejectors
- Rejector Systems : Belt Stop, Air Jet, Pusher, Falling Drop

Models :

Aperture Size	Sensitivity (Ø in mm)*		
100mm	Fe 0.5,	N Fe 0.8,	SS 1.2
120mm	Fe 0.7,	N Fe 1.2,	SS 1.7
150mm	Fe 0.9,	N Fe 1.5,	SS 2.2
200mm	Fe 1.2,	N Fe 1.7,	SS 2.7,

Models :

Model	MS 120
Detection Theory	Blanced Coil
Sensitivity Adjustment	Automatic or Manual
Standard Tube Size	Ø 120 mm
Alarm Mode	Buzzer and Lamp (Optional)
Reject System	Quik Flap System
Power Supply	AC 110V / 220V 50-60Hz
Rated Output	Appr. 200W
Dimensions	420mm (L) x 500mm (W) x 1300±10mm (H)

* Depends upon nature & weight of Product, Speed, Transport behaviour and environmental conditions.

WORLDWIDEMARKETING:

CITIZEN SCALE (I) PVT. LTD.

Unit No. E2, Plot No. 11, WICEL Estate, Opp. Seepz Gate No.1, Andheri (E), Mumbai 400 093. (INDIA)
 Tel. : +91-22-4243 7700 • Fax : +91-22-4243 7800 • E:mail : sales@citizenscales.com • Web : www.citizenscales.com